


GB Contents DE Inhalt FR Contenu NL Inhoud F Sisältö
 DK Indhold IT Contenuto ES Contenido PT Conteúdo
 GR Περιεχόμενα SE Innehåll

GB Getting started DE Erste Schritte FR Démarrage NL Aan de slag F Aloitusopas DK Kom i gang
 IT Operazioni preliminari ES Para empezar PT Para começar GR Πρώτα βήματα SE Kom igång



x2




x1



x2




x2



6mm



x1



x1






x2



CR2032

x1




x1



x1



3x AA/LR6




30mm






x1



x1








CR2032






15mm





GB Optional features DE Optionale Funktionen FR Options disponibles NL Opties
 FI Valinnaiset ominaisuudet DK Valgtrier funktioner IT Funzionalità opzionali
 ES Opciones disponibles PT Funções opcionais GR Προαιρετικές λειτουργίες πρόσθετων
 SE Möjliga funktioner



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



		3Hrs 			6Hrs
		9Hrs 			12Hrs



GB Linking DE Einlemen
 FR Programmation NL Verknüpfung
 FI Linkittäminen DK Forbinde
 IT Collegamento ES Enlace PT Pro-
 gramação GR Ούδωση SE Länkning



GB Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing
 FI Vianmääritys DK Problemløsning IT Risoluzione dei problemi ES Solución de
 problemas PT Resolução de problemas GR Αντιμετώπιση προβλημάτων SE Felsökning

livewell.honeywell.com



32305358-001 Rev.B