



# WIRELESS PUSH BUTTON INTERFACE

300 90 009



 [View on website](#)

## General info

<b>LOCATION</b>	interior
<b>INGRESS PROTECTION</b>	IP20
<b>WEIGHT (KG)</b>	0.1
<b>INFORMATION</b>	WIRELESS USER INTERFACE - BATTERY POWERED CONNECT UP TO 4 PUSH BUTTONS TO YOUR WIRELESS NETWORK

## Electrical info

<b>CLASS</b>	III
--------------	-----

## Remarks

[Click here for more information concerning Wireless Control by CTRL DELTA](#)

For detailed installation instructions, please consult the manual: [300\\_90\\_009\\_HAND.pdf](#)

Notes: